




SAVOY
HOUSE

ITEM NO: 7-2747-4



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Unravel the supply power and ground wires and pass them through the stem (I), top assembly (A), rods (B), rod (C), loop (D) and canopy (E).
4. Install stem (I) and socket assembly (H) to the bottom nipple of the top assembly (A).
5. Thread the bottom of rod (B) onto the top assembly (A). Repeat the process for remaining rods (B) and rod (C) as shown in the diagram, until snug. Install loop (D) onto the top of the rod (C).
6. Use carabiner (F) to connect loop (D) to the loop on the canopy (E) and twist the locking mechanism to secure.
7. Install tassels (G) onto the top assembly (A) as shown in the diagram.
8. Refer to the additional installation instructions included with the product for wiring and installation.
9. Install proper bulbs (not included) into each socket referring to the markings and/or labels on the fixture for maximum wattage.
10. Restore power to the installation point and retain this sheet for future reference.

Noted: If the hook on the tassel is retracted and not easy to install, use your thumb to gently push the hook out from under the sponge inside the tassel.